



PRESSURE

- Check tyre pressure monthly
- Look at the general conditions of tyres when checking cold tyre inflation pressure
- Recommended pressure charts indicate best tyre pressure for standard operating conditions
- Weigh the vehicle and adapt tyre pressure accordingly

GEOMETRY & BALANCE

- Check wheel alignment regularly
- Realise the impact of wheel balancing on tyres and vehicles



REGROOVING & RETREADING

- Regroove tyres when groove depth is down to 2-4mm
- Give tyres a new life and save raw materials with regrooving and retreading
- Go for high-quality retreads that will last longer